





OWNER'S MANUAL



PELLCO PRODUCTS, LLC

Loader Vise

OWNER'S MANUAL

Made in the USA. Patent Pending.

Thank you for purchasing LoaderVise.

We hope you find our invention as useful as we have, for many years to come!



INTENDED USE

This heavy-duty device is designed for the homeowner, small farm, or residential contractor.

It is designed for compact and sub compact tractors, skid steers and other residential/light commercial equipment.

!! SAFETY

It is strongly recommended that long sleeves, long pants, sturdy footwear, gloves and eye protection should be worn at all times when installing, removing or using this device.

If you are digging, any underground work should always begin with a call to your local underground authority (811, Miss Digg, etc.) to identify any existing below grade utilities and attain all necessary permits.

If you are lifting, pay close attention to your machine's capabilities and precautions.

Whether digging or lifting, please review your machines capabilities in your owner's manual.

Never lift a load more than 12" off the ground, and use caution when maneuvering under load.

INSTALLATION

LoaderVise is a heavy-duty simple solution to numerous tasks. No additional front loader hydraulics are needed. LoaderVise Installs and removes in minutes, with one person and simple hand tools.

This device requires minimal storage space.

The device will mount anywhere along the front edge of your loader bucket and is designed to fit many standard loader buckets; the device has a $\frac{3}{4}$ inch wide opening, 15" mounting depth, and accommodates up to a 4" wear bar.

LoaderVise is designed to fit both smooth and ribbed loader bucket bottom surfaces.

Simply slide the device into position and tighten the 4, grade 8 bolts to 30 ft. lb.'s.

Your loader bucket is strongest on the sides, and this is recommended for maximum visibility if you are using the digging bucket option.

Our imported digging buckets are high quality steel and guaranteed to fit your LoaderVise.

They are shipped separately, and may not arrive at the same time.

OPERATION

Never operate on anything other than level ground.

When removing LoaderVise from your machine, ensure the 4 mounting bolts are backed completely into the mounting nuts to prevent thread damage during removal and reinstall.

The digging option is ideal for trenching up to 22 inches deep and 7 inches wide, providing space for electrical conduits, drainage pipe and tile, French drains, rat walls, transplanting small trees and other vegetation.

Contact the soil in the desired location, pivot the bucket down as you reverse the tractor, lift the full bucket using your loaders boom up control and pivot to the side using the steering wheel and dump. Careful not to let your front wheel fall into the just dug trench.

The lifting option is achieved by attaching a clevis to one of the bucket bolts. Lifting should be done carefully in the center of the bucket, lift no more than 200 lbs. load should not be lifted above 12" off ground, keeping your loaders capacity and capability in mind.

ABOUT US

We are a small American business located in the U.S. state of Michigan. LoaderVise is proudly produced with American steel, by American workers - in the USA.

LoaderVise is a heavy-duty option for your digging and lifting needs, the upright frame is ½" plate steel, and mounting wings are ¼" plate steel.

Nuts and bolts are grade 8 heavy duty and will last for many cycles.

We thank you for purchasing from our U.S. small business!

Contact us at our website: LoaderVise.com

When used correctly, your LoaderVise will give years of service.

TERMS OF USE & LIMITATIONS

LoaderVise and Pellco Products are not responsible for failure to follow safety and use instructions listed above.

We will not be held liable for any damages resulting from use of this product, either to equipment, environment, utilities or personal injury. Please follow instructions in this manual.

Excavation Damage: Pellco Product LLC and LoaderVise are not responsible for "ANY AND ALL" property & bodily injury liability claims.

Equipment Damage From Overload: Pellco Product LLC and LoaderVise are not responsible for overload damage to your equipment from the operation of Any Pellco Product.

Hold Harmless & Waiver of Subrogation: When you purchase our products YOU agree to Hold Harmless & Waive all Rights to Subrogate against Pellco Product LLC and LoaderVise.